


# Phase Noise Test Set

UR




▲  
PLL  
▼



+60dB  
LNA  
+30dB

REF



●  
PLL

ON  
OFF

Quadratur-Monitor (-3 / +10dBm)

AMP (+7 / +20dBm)

0dB  
DUT